



NOTES:

1. DO NOT SAWCUT AC AT FACE OF CURB.
2. SAWCUT SHALL EXTEND THROUGH FULL DEPTH OF CURB (16")
3. IF ASPHALT IS DAMAGED WHEN CURB IS REMOVED DAMAGE SHALL BE REPAIRED BY THE CITY. UNDER NO CIRCUMSTANCES SHALL CONCRETE BE PLACED BEYOND THE FRONT FACE OF THE CURB (IN ASPHALT AREA). PROVIDE BLOCKING AT FRONT FACE OF FORMS TO KEEP CONCRETE OUT OF ASPHALT AREA.
4. WHEN FINAL PAVING LIFT HAS NOT YET BEEN PLACED USE 2 1/2" LIP.

**CITY OF SANDY**

**CURB KNOCKOUT  
FOR DRIVEWAYS**

DATE:

NOV 1997

DRAWING NO.

**211**